

## XCiPhone Installation Guide for ATEX Zone 2 cases



Remove from the bag front and rear case parts, belt clip and the Warranty Void labels.

Have the iPhone cleaned and ready for installation with SIM card inserted.



Place the iPhone into the top case with the screen facing down and ensure it is fully inserted.

Check iPhone functionality. Screen and buttons.



Place bottom case onto top case and ensure aligned correctly



Push down hard to seal the two case halves. Start in on corner and work round the case until fully sealed



Carefully check that the seal is complete the whole way round the join



Finally attach the Warranty void labels over the seam between top and bottom



The XCiPhone is now installed and safe to use.  
Ensure the Safety Instructions are followed at all times and if there is any indication of failed integrity of the case immediately switch off phone and remove from hazardous area.