

Legal Notices

This manual and any examples contained herein are provided "as is" and are subject to change without notice. JNC makes no warranty of any kind with regard to this manual, including, but not limited to, the implied warranties of merchantability, non-infringement and fitness for a particular purpose. JNC shall not be liable for any errors or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual or the examples contained herein.

Reproduction, adaptation or translation of this manual is prohibited without prior written permission of JNC Service B.V.

CAUTION: This Quick Reference Guide may be revised or withdrawn at any time without prior notice.

This document provides basic instructions for setting up your DOKKi.eu DMT-1 docking station.

The DMT-1 will fit both Opticon scanner models OPN-2001 and OPN-2002. Before inserting an OPN-2002 be sure to remove the rubber USB cover (if any).



Other models (for example the OPN-2003) won't fit.
Trying to insert unlisted models will result in damage to the DMT-1 and other scanner model!

BOX CONTENTS

The box contains the DMT-1 docking station. Promotional items aren't listed here.

DRIVER INSTALLATION

The DOKKi.eu DMT-1 itself does not need a separate driver. The only driver that needs to be installed on your PC is the appropriate driver for your scanner model (OPN-2001 or OPN-2002) that you wish to use on the DMT-1. If not already done so, please follow the instructions for driver installation in the corresponding manual that belongs to your scanner model.

PHYSICAL CONNECTION

Connecting your DMT-1 docking station to your host computer is done with the original USB host cable that was supplied with your OPN-2001 or OPN-2002.

1. Connect the USB A (male side) of the host cable to a free USB port on your PC;
2. Connect the mini-USB (mini B5 male side) connector on your USB host cable to back of your DMT-1 docking station.



You are now ready to use your DMT-1 docking station!

DOCKING YOUR SCANNER

Simply connect your OPN-2001 or OPN-2002 to the docking station by gently placing the OPN over the DMT-1 to align the connectors. When aligned press the scanner down to secure the connection.



Press firmly but never use excessive force when pressing down as this might damage the connectors!
Check for obstructions on both connectors and retry connection.

TROUBLESHOOTING

If you are experiencing any problem with the DMT-1 the first thing to check is if the OPN functions correctly when connected directly to the USB cable. Do so by unplugging the USB cable from the back of the DMT-1 docking station and plug it directly into your OPN. If it does function properly continue at the checklist below, otherwise the problem is with your OPN itself, the USB cable or the PC (USB port and/or driver(s)).

Checklist

No power	- Is the OPN scanner firmly pressed into the docking station?
	- Are the cables properly connected?
	- Is the PC switched on?

No communication	- Is the OPN fully charged?
	- Are the OPN drivers properly installed?
	- Are there no other programs polling on the same COM-port?

If you have any questions regarding the use of the DOKKi.eu DMT-1 docking station please contact your dealer.

BY OPENING THE PACKAGE OF THIS PRODUCT YOU AGREE TO BECOME BOUND
BY THE LIABILITY AND WARRANTY CONDITIONS.

Limited Warranty, Liability and Disclaimers

This Limited Warranty and Disclaimer extends only to products purchased directly from DOKKi.eu or a DOKKi.eu Authorized Dealer as stated on our website (<http://www.dokki.eu/dealers>).

Under no circumstance JNC will be liable for any direct, indirect, incidental, special, consequential, punitive, or exemplary damages, including but not limited to, damages for loss of profits, revenue, income, goodwill, use, data, or other intangible losses that arise from use or inability to use the DMT-1, even if JNC has been informed about the possibility of such damages.

The DOKKi.eu DMT-1 is warranted for a period of one year after purchase, covering defects in material and workmanship. JNC will repair or, at its opinion, replace products that prove to be defective in material or workmanship under proper use during the warranty period. The warranty does not apply to defects resulting from (a) improper or inadequate maintenance measures taken; (b) interfacing parts or supplies not supplied or authorised by JNC; (c) unauthorized modification or misuse; (d) operation outside the applicable environmental parameter limits specified for the product; or (e) improper site preparation or maintenance for installation.

Outside The Netherlands, return the product to your dealer. Follow the instructions provided by your dealer.