

DISINFECTS ANY TYPE OF ITEM ELIMINATING VIRUSES, BACTERIA, MOLD AND FUNGI



THE SANITIZING CYCLE

SANItize box is extremely safe and easy to use; its operating process consists of a few simple steps:

- Place the item to treat in the sanitization chamber.
- Close the cover and start the cycle by simply pressing the START / STOP button.

The sanitizing cycle has a duration of 25 minutes, but you can stop it at any time by pressing the START / STOP button.

During the first cycle phase, lasting 20 minutes, the system distributes ozone in the sanitization chamber, obtaining a homogeneous treatment on the entire item surface. The final cycle phase, lasting 5 minutes, is used instead to break down the ozone molecules: upon completion, any residual ozone will be harmless and will be dispersed immediately once the cover is opened.

THE INNOVATION OF SANITIZE BOX

SANITIZES ITEMS SAFELY

OPERATION IS FULLY

AUTOMATIC

EASY TO USE AND MAINTENANCE-FREE

OPERATING AND PRODUCTION ZERO
COSTS ARE EQUAL TO

DISINFECTS OZONE
USING ONLY
WITHOUT ANY CHEMICAL SUBSTANCES





