

Legal Notices

This manual and any examples contained herein are provided "as is". JNC makes no warranty of any kind with regard to this manual, including, but not limited to, the implied warranties of merchantability, non-infringement and fitness for a particular purpose. JNC shall not be liable for any errors or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual or the examples contained herein.

Reproduction, adaptation or translation of this manual is prohibited without prior written permission of JNC Service B.V.

CAUTION: This Quick Reference Guide may be revised or withdrawn at any time without prior notice.

This document provides basic instructions for setting up your DOKKi.eu CMT-6 docking station.

The CMT-6 will fit Opticon scanner models OPN-2001, OPN-2002 and OPN-2005. Before inserting an OPN-2002/OPN-2005 be sure to remove the rubber USB cover (if any). Keep the cover in case it's needed at a later stage.

The insertion area is as tight as possible to ensure stability for the OPN scanner. That also means that the OPN won't fit any more when used in combination with any available OPN sleeve or case (rubber, leather, etc.).



***Other models (for example the OPN-2003 and OPN-2004) won't fit.
Trying to insert unlisted models will result in damage to the CMT-6 and other scanner model!***

UNPACKING



Do NOT use a knife to open the package or contents as this may result in damaging the product(s)!

Open the outer box on the top-side. Take the CMT-6 from it's box and remove the bubble-foil.

BOX CONTENTS

- CMT-6 docking station
- power adapter
- USB cable

Promotional items aren't listed here.



CMT-6 powered with
6 OPN's inserted

POSITIONING

The CMT-6 has rubber feet on the bottom and can be used as a desk-stand. Please make sure the CMT-6 is positioned on a firm background which is levelled.

POWER AND CONNECTION

After unpacking and positioning, simply connect the power adapter to the back of the CMT-6 and the other end in the wall outlet.



CMT-6 rear view: power and USB connection

Now all 6 ports are ready to charge any mix of up to six OPN-2001's, OPN-2002's and/or OPN-2005's.

CMT-6 USAGE SAMPLES

- **CHARGE ONLY**
You can use the CMT-6 as a 'charge only dock'.
This way all six ports are connected to the powered USB hub which resides inside the CMT-6.
- **COMMUNICATION AND CHARGING (MIXED)**
You also can use all ports to communicate with the PC. For this connect the CMT-6 with the supplied USB cable to a PC. Remember: each position on the CMT-6 will create it's own random Virtual Com Port (VCP) on the PC when a scanner is inserted, so make sure your software is able to handle this!

DRIVER INSTALLATION – ONLY NECESSARY WHEN USING THE CMT-6 FOR COMMUNICATION TO PC

The DOKKi.eu CMT-6 itself does not need a separate driver. The only driver that needs to be installed on your PC is the appropriate driver for your scanner model (OPN-2001, OPN-2002 or OPN-2005) that you wish to use on the CMT-6. If not already done so, please follow the instructions for driver installation in the corresponding manual that belongs to your scanner model.

DOCKING YOUR SCANNER

Hold the scanner between your thumb and index finger on the OPN's body where USB connector is situated in the side (thus, not in the middle but more to the left side, USB connector pointing downward). Simply connect your scanner to the docking station by gently placing the OPN over the CMT-6 to align the connectors. When aligned press the scanner down to secure the connection.



Press firmly but never use excessive force when pressing down as this might damage the connectors!
Check for obstructions on both connectors and retry connection.

ACCESSORIES

- Mount Kit to securely mount the CMT-6 in a fixed place.

All (other) available accessories can be found on our website.

TROUBLESHOOTING

If you are experiencing any problem with the CMT-6 the first thing to check is if the OPN functions correctly when connected directly to the PC with an USB cable. Do so by plugging the USB cable that came with your scanner into your OPN and make sure the other end of the USB cable goes directly into the PC, bypassing any present HUB.

If it does function properly continue at the checklist below, otherwise the problem is with your OPN itself, the USB cable or the PC (USB port and/or driver(s)).

Checklist

No power *1	<ul style="list-style-type: none"> - Is the OPN scanner firmly pressed into the docking station? - Are the cables properly connected? - Is the PC switched on?
No communication *1	<ul style="list-style-type: none"> - Is the OPN fully charged? - Are the OPN drivers properly installed? - Are there no other programs polling on the same COM-port?
<i>*1 and if connected to a powered USB hub</i>	<ul style="list-style-type: none"> - Is the power-supply of the USB hub plugged in? - Is one port on the USB hub failing, or are all ports faulty? - Is the USB cable securely fitted on both ends?

If you have any questions regarding the use of the DOKKi.eu CMT-6 docking station please contact your dealer.

BY OPENING THE PACKAGE OF THIS PRODUCT YOU AGREE TO BECOME BOUND
BY THE LIABILITY AND WARRANTY CONDITIONS.

Limited Warranty, Liability and Disclaimers

This Limited Warranty and Disclaimer extends only to products purchased directly from DOKKi.eu or a DOKKi.eu Authorized Dealer as stated on our website (<http://www.dokki.eu/dealers>).

Under no circumstance JNC will be liable for any direct, indirect, incidental, special, consequential, punitive, or exemplary damages, including but not limited to, damages for loss of profits, revenue, income, goodwill, use, data, or other intangible losses that arise from use or inability to use the CMT-6, even if JNC has been informed about the possibility of such damages.

The DOKKi.eu CMT-6 is warranted for a period of one year after purchase, covering defects in material and workmanship. JNC will repair or, at its opinion, replace products that prove to be defective in material or workmanship under proper use during the warranty period. The warranty does not apply to defects resulting from (a) improper or inadequate maintenance measures taken; (b) interfacing parts or supplies not supplied or authorised by JNC; (c) unauthorized modification or misuse; (d) operation outside the applicable environmental parameter limits specified for the product; or (e) improper site preparation or maintenance for installation.

Outside The Netherlands, return the product to your dealer. Follow the instructions provided by your dealer.